





























BOOK  
M38 - B1171



# MUSIC BOX





**22** X2 X2 X4 X2 X2 X2

**23** X2 X2 X2

**24** X2 X2 X2

**25** X2 X2 X2 X2 X2 X2

**26**

**27**

**28** X1 X4 X4 X4 X4

**29** X2 X2 X2 X2 X2 X2

**30** X2 X1

**31** X1 X4

**32** X8 X8 X8 X8 X8 X8 X8 X8 X16

**33** X8 X8 X8 X8 X8 X8 X8 X8

**34** X8 X8 X16 X8 X8 X16

**35** X8 X8 X8 X8 X8 X8 X8 X8

**36** X8 X8 X16 X8 X8 X16

**37** X4

**38**

**39**

**40** X1 X2

**41** X1 X1 X2

**42** X1 X1 X1 X1 X1 X1 X1 X1

**43** X1 X1 X1 X1 X1 X1 X1 X1

**44**

**45** X1 X1 X1 X2

**46** X1 X1 X1 X2

**47** X1

**48** X1 X4 X4

**49**

**50** X1

**51** X1 X1 X1 X1

**52** X4 X4

**53** X4 X4 X4

**54**

**55** X1 X1 X1 X1

**56**

**57**

**58**

**59**

**60**

**61**

**62**

**63**

**64**

**65**

**66**

**67**

**68**

**69**

**70**

**71**

**72**

**73**

**74**

**75**

**76**

**77**

**78**

**79**

**80**

**81**

**82**

**83**

**84**

**85**

**86**

**87**

**88**

**89**

**90**

**91**

**92**

**93**

**94**

**95**

**96**

**97**

**98**

**99**

**100**

**M38 - B1168**

**M38 - B1169**

**M38 - B1170**

**该说明书含有重要信息。必须给予保留！**  
 Keep this instruction manual for reference since it contains important information.

**WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.**